


Audio Interface Operation

- 1 Connect the included USB cable to the left (USB audio) jack labeled 
- 2 Connect the other end of the cable to your phone, tablet or computer *
- 3 Connect a microphone to an XLR input on the front panel of the PortCaster
- 4 Connect headphones to the headphone output
- 5 Start your audio app and you are ready to record!

* For iOS devices use Apple Lightning to USB Adapter if needed.







For Best Results

- Make sure CourtCaster is selected as the default I/O device in your audio app
- For condenser mics, turn on 48V phantom power (move switch to the right)
- Adjust microphone level with the GAIN knob. Adjust headphone level with the MONITOR knob.
- Use the MONO/STEREO blend control to mix the program to mono for some streaming apps.
- Use the INPUT/USB blend control to balance the input monitor with the USB return. This is the zero latency monitor.
- Use the MIC/PHONE switch to select either XLR jack or TRRS jack as input for Channel 2.

Mix-minus feature:

A connected phone will hear the monitor output of the PortCaster minus the voice of the caller to prevent audio feedback.

Recorder Operation

-  Press PLAY/STOP to start or pause playback. Status LED turns solid green during playback.
-  Press RECORD to start recording. Status LED turns solid red. Press PLAY/STOP to stop.
-  Pressing PREVIOUS will replay a track OR play a previous track, until the first track is reached.
-  Pressing NEXT will play the next track, until last track is reached.

For Best Results

- Use micro SD cards from known brands, with these labels (or better):



- To insert the card, push the card into the socket until it clicks into place. Push again to eject.
- Do not eject the card while recording. Data will be lost. Press PLAY/STOP before ejecting.
- Cards larger than 32GB should be formatted with PortCaster before use. Warning: Formatting will erase all data on the card.

