



## Quick Start Guide

- 1 Turn the unit on/off by pressing and holding the power button  for 2 sec.
- 2 Attach the included USB cable to the left (USB audio) jack labeled 
- 3 Attach the other end of the cable to your phone, tablet or computer \*
- 4 Attach a microphone to an XLR input on the front panel of the MicPort Pro
- 5 Attach headphones to the headphone output
- 6 Start your audio app and you are ready to record!

## For Best Results

- Make sure “CEntrance MicPort Pro” is selected as the default I/O device in your audio application
- If using a condenser microphone, make sure the 48V phantom power switch is on (to the right)
- Adjust microphone level with the GAIN knob. The MONITOR knob feeds both the headphone and balanced outputs.
- Use the CH/USB blend control to balance the input monitor with the USB return. This is the zero latency monitor.

\* For iOS devices use the Lightning to USB adapter. See our website.

Line / Hi-Z switch



Low cut filter



Input GAIN



Monitor blend



Headphone monitor level



#centrance  
#micportpro

**CEntrance**  
www.centrance.com

**MicPort Pro 2**  
Mobile Recording Interface